

Octagon and Oval Window Installation Instructions.



- Begin by placing 1x2.1/4" filler strips onto floor.



- Align filler strips to center of post on both sides and floor splice.



- Attach all filler strips to floor through pre-drilled holes

- Use 2" Brown Screws for Wood Gazebos

- Use 1.1/2" Composite Screws for Vinyl Gazebos



- Place first window Panel into place with bottom of the window behind the filler strip

- Push the top of the window against the posts and center in opening.



- Temporarily hold first window panel in place while installing second window panel in the next opening beside first panel



-After the first two window panels are in place, place the provided T-Strip between window panel onto post.



- Ensure T-Strip is centered on post as shown



- Attach T-Strip to Post Using the provided Screws.



- Finish by Installing the remaining windows using the Same Previous Steps.